



INSTALLATION SYSTEMS

Product	Series	Widths	Installation System	Adhesive	Trowel Size	Seaming	Seam Sealer
Rustic™	47000	12'	Full Spread or Glueless	Parabond® M4223 or Armstrong S-235	Use manufacturers recommended trowel notch.	Double-cut dry. Use Domco Seam Tape.	DT-65
Rustic A Series™	A0000	12'	Full Spread or Glueless	Parabond® M4223 or Armstrong S-235	Use manufacturers recommended trowel notch.	Double-cut dry. Use Domco Seam Tape.	DT-65
Elite®	56000	12'	Full Spread or Glueless	Parabond® M4223 or Armstrong S-235	Use manufacturers recommended trowel notch.	Double-cut dry. Use Domco Seam Tape.	DT-65
Image™	62000	12'	Full Spread or Glueless	Parabond® M4223 or Armstrong S-235	Use manufacturers recommended trowel notch.	Double-cut dry. Use Domco Seam Tape.	DT-25
Cerama®	66000	12'	Full Spread or Glueless	Parabond® M4223 or Armstrong S-235	Use manufacturers recommended trowel notch.	Double-cut dry. Use Domco Seam Tape.	DT-65
Eloquence™	70000	12'	Full Spread or Glueless	Parabond® M4223 or Armstrong S-235	Use manufacturers recommended trowel notch.	Double-cut dry. Use Domco Seam Tape.	DT-65
Ambiance® (VersaFloor™)	L0000	12'	Full Spread or Glueless	Parabond® M4600	Use manufacturers recommended trowel notch.	Double-cut dry. Use Domco Seam Tape.	DT-65
Trends® (VersaFloor™)	L3000	12'	Full Spread or Glueless	Parabond® M4600	Use manufacturers recommended trowel notch.	Double-cut dry. Use Domco Seam Tape.	DT-65