



## TRENDS® VERSAFLOOR

---

### PRODUCT SPECIFICATIONS

<b>Wearlayer:</b>	Urethane (Low Gloss)
<b>Nominal Wearlayer Thickness:</b>	.010" (0.25mm)
<b>Nominal Total Thickness:</b>	.080" (2.0mm)
<b>Widths:</b>	12' (3.6m)
<b>Roll Size (Sq. Yds.):</b>	115 (96 sq.m)
<b>Weight per Sq. Yd. (Lbs.):</b>	2.85(1.29kg)
<b>ASTM F-970 Static Load Limit:</b>	75 lbs/in <sup>2</sup> (34 kg/cm <sup>2</sup> )
<b>ASTM F 1303:</b>	Type I, Grade 3, Class C
<b>HUD/FHA Minimum Property Standards:</b>	Meets Wearlayer Thickness Requirement

### INSTALLATION

<b>Use:</b>	Residential.
<b>Installation System:</b>	Glueless or Full Spread.
<b>Location:</b>	Below, on and above grade concrete, above grade plywood.
<b>Fitting:</b>	Freehand or pattern scribe.
<b>Adhesive:</b>	For full spread installations use Domco DT-VinylBond™.
<b>Trowel Notch:</b>	1/32" (0.8mm) deep x 1/16" (1.6mm) wide x 1/32" (0.8mm) apart.
<b>Seam Method:</b>	Double-cut dry. Adhere seam area with Domco Seam Tape.
<b>Seam Sealer:</b>	Domco DT-65 Seam Sealer.

- Keep material rolled face out on a sturdy core until time of installation.
- Maintain room temperature, flooring and adhesive at 65°F (18°C) for 48 hours before, during and after installation.
- Use only hydraulic (portland) cement based patching and leveling compounds where needed.
- Use a high quality embossing leveler when installing over approved existing flooring where needed.
- Unroll flooring and allow material to relax for 20-30 minutes before fitting.
- When installing using the "Glueless" Installation System, leave a 1/8" - 1/4" space between flooring and all verticals (walls, pipes, cabinets, etc.).
- Installations requiring more than one seam over wood construction must be fully adhered using Domco DT-VinylBond™.
- When using a full spread application, roll flooring in both directions with a 75-100 lb. (34-45kg) sectional floor roller.
- Protect sealed seams from all traffic for a minimum of 3 hours.

### CARE AND MAINTENANCE

- Do not replace frequently moved furniture or allow heavy traffic for at least 24 hours on adhered installations.
- Never slide heavy furniture or appliances across the floor. Place plywood on the floor and move the object across the plywood.
- To minimize scratching and indentations, equip tables and chairs with proper floor protectors.
- Sweep or vacuum to remove loose dirt or debris that can scratch the floor.
- Wipe up all spills promptly with a damp cloth or mop.
- Wash floor with Domco SureShine Floor Cleaner or equal neutral floor cleaner designed for sheet vinyl flooring.
- The use of non-staining mats can remove dirt and debris in the entryways and help prolong the life of the floor.

### WARRANTY

- 10 Year Wear and Manufacturing Defects.
- 10 Year Rip, Tear and Gouge.
- 10 Year Moisture Stain.
- 10 Year Asphalt Stain.
- 10 Year Underlayment Panel Stain.