



VersaFloor™ Installation Tips

- Flooring can be transported rolled face in or out on a sturdy core.
- Room temperature shall be no less than 65°F (18°C) during installation.
- VersaFloor™ may be installed over gypsum based underlayments using the Glueless Installation System.
- Undercut door moldings to allow flooring to slide under the molding.
- Unroll the flooring in the room and allow it to relax approximately 20 minutes before fitting. To reduce this waiting time, the flooring may be back rolled (pattern side in) on a core prior to transporting to the jobsite.
- There is no maximum length for the installation of VersaFloor™. However, long lengths of flooring may have a tendency to bow or twist during layout or positioning. Use caution to insure that the material is lying completely flat and is aligned squarely within the room before final fitting and/or cutting of seam.
- Leave a 1/8" - 1/4" space between flooring and all verticals (i.e. walls, cabinets, pipes, etc.).
- Do not fasten cabinets through VersaFloor™.
- **DO NOT PERIMETER BOND VERSAFLOOR™.**
- One seam per installation is allowable when installing on a wood substrate. If an installation requires more than one seam over a wood substrate, the flooring shall be fully adhered using Domco DT-VinylBond™ Adhesive.
- Multiple seams are allowable when installing over a concrete substrate.
- Once seam overlap is achieved, place strips of masking tape across the seam to prevent shifting. Seams are cut using the double-cut dry method only. Do not straight edge and butt seams.
- Seams are fastened using Domco Seam Tape.
- If an installation requires the floor to be net fit, the flooring must be fully adhered using Domco DT-VinylBond™ Adhesive.
- Install wood moldings or cove base around the perimeter to cover the space. Do not nail moldings through VersaFloor™. Nail into the wall.
- Install doorway transition moldings. Do not nail through VersaFloor™.
- Seal seams with Domco DT-25 Seam Sealer for materials with high gloss finish and Domco DT-65 Seam Sealer for materials with low gloss finish.
- Carefully inspect for any fullness in the flooring. Re-trim if necessary.